

Mounting instruction

ECOFLEX® 10 / AIRCOM PLUS®
BNC-Connector / Art. Nr.: 7379



1



Cut off cable tail right-angled.

2



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.

3



Remove 6 mm of the outer sheath with a knife.

4



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.

5




Remove the copper foil and the dielectric with a knife.

6



Stick inner pin onto the inner conductor and solder carefully. Put on the Teflon-Isolator. Hint:
Pin 1: 2,8mm Ø AIRCOM PLUS
Pin 2: 3,0mm Ø ECOFLEX 10.

7



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain visible between clamping nut and connector housing.