Maintenance 6 - 41

Remote Mount Enhanced Control Head – Exploded View and Parts List




Figure 6-56 Remote Mount Enhanced Control Head – Exploded View

Table 6-9 Remote Mount Enhanced Control Head – Parts List

Item No.	Description	Part No.
1	Remote FFC (Main to Remote)	8471921L01
2	Remote PWA Kit	0104037J05
3	Remote Back Housing Assembly	0104025J30
4	D Sub Cover	1571012L01
5	Trunnion	PMLN4912_
6	Middle Screw	0371912L01
7	Self Tapping Screw	0316961H01